

McDonnell & Miller

Installation & Maintenance Instructions MM-309(E)


Replacement Cartridge and Strainer Kit


For Series:

47, 51, 101-A

247, 551S, 847, 851,

Water Feeders with Hex Port Valves





WARNING



• Before using this product read and understand instructions.

· Save these instructions for future reference.

- My
- All work must be performed by qualified personnel trained in the proper application, installation, and maintenance of plumbing, steam, and electrical equipment and/or systems in accordance with all applicable codes and ordinances.



Failure to follow this warning could cause property damage, personal injury or death.


INSTALLATION –

TOOLS NEEDED:


One (1) 13/16" (21mm) socket wrench and one (1) 1/2" (13mm) wrench.

STEP 1 - Preparation

a. Turn off the power to the boiler.




b. Allow the boiler to cool to 80°F (27°C) and close the two (2) gate valves (A) in the system piping.



STEP 2 - Remove the Original Cartridge and Strainer

- a. Using the 1/2" (13mm) wrench, unscrew and remove the four (4) hex-head screws (B) that secure the strainer. Discard the strainer (H) and the gasket (C).
- **b.** Using a 13/16" (21mm) socket wrench, unscrew the old cartridge (D) from the valve body (E) and discard it.


NOTE: The cartridge (D) will either be black (Series 101-A, 47, 247 and 847) or gray (Series 51, 851 and 551-S) and should be replaced with a similarly colored replacement cartridge.




STEP 3 - Install the New Cartridge and Strainer

a. Apply lubricant (provided) to the two (2) O-rings (E) on the new cartridge (F).


NOTE: Use the silicone grease provided in red capsule. The use of other lubricants may cause premature cartridge failure.



b. Using the 13/16" (21mm) socket wrench, screw the new cartridge (F) into the valve body (E). Tighten to approximately 2 ft•lb (2.6 N•m). DO NOT OVER TIGHTEN.




c. Place the gasket (C) in the groove on the strainer assembly (G) and insert the strainer (H). Using a socket wrench, tighten the four (4) bolts to 8 ft•lb (11 N•m).





McDonnell & Miller

d. Open the gate valves (A) by turning the handles counter-clockwise.



MAINTENANCE

SCHEDULE:

- Disassemble and inspect the strainer screen annually. Thoroughly clean the strainer screen or replace.
- Remove and inspect cartridge annually. Thoroughly clean by rinsing with clear water or replace.